







push here to see if it can push forward and rebunce.

If not, spray WD40 to make sure this part can push forward and rebunce.



if the foot pedal easy to press down, you may need to loss this nut a little bit (anticlock way)

*DO NOT ADJUST TOO MUCH,
THIS NUT CONNECTED WITH
BRAKE PAD)



DO NOT LOSS TOO
MUCH THE NUT, NEED
TO MAKE SURE THE
NUT CONNECTED THE
BRAKE PAD WELL.



Lift the foot pedal to the up position, then put the shaft cross in then put the circlip back